Granite Quick Troubleshooting-Panasonic KX-TGP600

Status Light Indicators	
STATUS Indicator	
Solid Green	The base unit is connected to the internet and connected to the HPBX Small Office system.
	The base unit is being used for a call OR the base unit is downloading data. Do not disconnect the Ethernet cable or AC power adaptor from the base unit until the light
Slow Flashing Green (once a second)	becomes solid green
Quick Flashing Green (4 times a second)	The handset/ desk phone is busy
Solid Red	The base unit is booting up. This will take about 40 seconds
Slow Flashing Red (once a second)	The base unit is registering a handset/desk phone
Quick Flashing Red (4 times a second)	The base unit is paging handsets/desk phones (by using the handset locator button)
Solid Yellow	The base unit's IP address may conflict with another IP address on your network
Slow Flashing Yellow (once a second)	The base unit is attempting to connect to the Internet or to the HPBX Small Office system. Please wait. If it flashes indefinitely, check your network settings, ensure your internet connection is working, or try restarting all your devices.
Quick Flashing Yellow(once a second)	Unplug the base unit's AC adaptor to reset the unit, then reconnect the AC adaptor. If it is still flashing, there may be a problem with the base unit hardware
Slow switching (Red> Amber> Off)	The base unit is in maintenance mode. Once it is off, turn the base until back on again
Quick switching (Red> Green> Amber> Off)	The base unit is restarting, please wait.

Registering Using the Base Unit

1. On the base unit, press and hold the handset locator button for about 3 seconds (the button is located on the right side of the unit). The status indicator on the base unit will flash red.

2. On the desk phone/ cordless handset, press and hold **OK** until the display shows "**Please Wait...**". The registration is complete when the display shows "**Registered**".